

SPARE PARTS OF BASSO C29/70-A2 COIL NAILER

ITEM	PARTS NO	PARTS NAME
101	2040101-04111-2	HEX.SOC.HD.BOLT
102	11369-0865301-2	CAP
103	1135S-0350001-1	GROMMET
104	2040104-03010-0	HEX.SOC.HD.SCREW
105	11397-0864701-1	GUIDE COVER
106	11302-0864701-1	CYLINDER CAP SEAL
107	11370-0860001-1	SEAL
108	11360-0354701-3	COMPRESSION SPRING
109	2041108-05070-0	O - RING
110	11381-0864701-1	WASHER
111	11368-0860001-3	HD.VALVE PISTON
112	2041108-06050-0	O - RING
113	2041108-05060-0	O - RING
114	11204-0860003-2	DRIVER UNIT
115	11399-0860001-1	COLLAR
116	11320-0860001-1	CYLINDER
117	2041108-06010-0	O - RING
118	11321-0860001-1	CYLINDER SPACER
119	2041101-09020-0	O - RING
120	2041100-06010-0	O - RING
121	11327-0864701-1	BUMPER-A
122	11327-0864702-1	BUMPER-B
123	1135S-0860001-1	GROMMET A
124	11362-0864701-1	DOOR SHAFT PIN
201	2041104-02060-0	O - RING
202	11374-0860001-1	PLUNGER CAP
203	2041100-02050-0	O - RING
204	2041100-01070-0	O - RING
205	1133S-0860001-1	VALVE PLUNGER
206	2041100-01030-0	O - RING
207	11376-0860001-1	SPRING
208	2041108-01020-0	O - RING
209	11375-0860002-1	PLUNGER
210	11373-0860001-1	TRIGGER VALVE HEAD
211	11329-0860001-1	PIN
212	1137A-0860001-1	COVER-PLUNGER
213	2041104-02070-0	O - RING
214	2041100-01050-0	O - RING
215	2040401-05100-0	SPIRAL PINS
216	11317-0864701-2	SECONDARY TRIGGER
217	11316-0864701-3	TRIGGER
218	2040401-05080-0	SPIRAL PINS
219	2040401-05120-0	SPIRAL PINS
301	11230-0865201-1	GUN BODY UNIT
302	2041101-05020-0	O - RING
303	11346-0864303-1	END CAP
304	1132L-0014701-2	DUSTY COVER
305	1135V-0000021-3	AIR PLUG
401	2041108-06060-0	O - RING
402	2041108-01010-0	O - RING
403	11382-0864702-1	NOSE PIECE
404	2040101-05040-1	HEX.SOC.HD.BOLT

405	2041100-01091-0	O - RING
406	11364-0864701-1	FEED PISTON
407	2041100-03051-0	O - RING
408	1134W-0860001-1	FEED BUMPER
409	11367-0860001-1	PUSHER SPRING
410	11366-0864701-1	FEED PISTON CAP
411	2040300-02010-0	C - RING
412	2040101-04131-0	HEX.SOC.HD.BOLT
413	11310-0954701-1	DOOR LATCH
414	11311-0860001-1	LATCH SPRING
415	11361-0864702-1	DOOR
416	1135H-0860001-1	PU RETAINER
417	2040400-05060-0	SPRING PIN
418	1133C-0860001-1	STOPPER FINGER SPRING
419	11358-0864701-1	NAIL STOP
420	11359-0864701-1	PIN-NAIL STOP
421	11383-0860001-1	MUZZLE PROTECTOR
422	1134B-0864701-1	DUST SHIELD PLUG
423	11330-0864702-1	SAFETY
424	11337-0864701-1	SAFETY SPRING
425	11338-0864701-2	SAFETY GUIDE
426	11354-0864701-3	MAGAZINE CASE
427	11357-0860001-4	ADJUST POST
428	2040301-24010-0	C - RING
429	1134M-0864701-1	SPRING BASE
431	11259-0864701-1	NAIL BRACKET UNIT
432	1138W-0860001-1	SPACER
433	11328-0860001-1	PULL SPRING
434	11355-0864703-1	MAGAZINE COVER
435	11365-0864701-1	PIN FEED PISTON
436	11306-0864701-1	FEED FINGER
437	11307-0864701-1	FEED FINGER SPRING
438	2040101-04121-2	HEX.SOC.HD.BOLT
439	1135U-1010001-1	PROTECTOR WASHER
441	1134R-0864701-1	SPRING COVER
442	2040501-04010-0	BOLT CAP
443	1136R-0864701-1	MAGAZINE SHAFT PIN
444	2040200-06011-0	SPRING WASHER