

SPARE PARTS OF BASSO C33/90-A3 COIL NAILER

ITEM	PARTS NO	PARTS NAME
101	2040103-05010-2	COUNTER SUNK SCREW
102	1136B-0374701-1	DEFLECTOR PAD
103	11371-0374701-2	DEFLECTOR
104	1135G-0374701-1	RUBBER PAD
105	1135S-0350001-1	GROMMET
106	2040100-04060-2	BOLT ASSY
107	11369-0375301-3	CAP
108	2040104-03010-0	HEX.SOC.HD.SCREW
109	1136C-0374701-1	POSITIONING AXIS
110	11376-0254701-1	SPRING
111	2040104-04010-0	HEX.SOC.HD.SCREW
112	11360-0374701-3	COMPRESSION SPRING
113	11368-0370002-3	HD.VALVE PISTON
114*	2041109-05070-0	O - RING
115*	2041108-07021-0	O - RING
116*	2041109-05080-0	O - RING
117	1136N-0370001-3	VALVE
118	11399-0370001-1	COLLAR
119*	11370-0370002-1	SEAL
120	2040102-04010-0	HALF ROUND HD.HEX.BOLT
121*	11302-0374701-3	CYLINDER CAP SEAL
122*	2041107-06010-0	O-RING
123	11204-0790017-3	DRIVER UNIT
124	1135J-0370001-2	PRESS RING
125	11320-0370003-1	CYLINDER
126	2041101-06010-0	O - RING
127	11322-0370002-1	CYLINDER RING
128	11321-0370001-2	CYLINDER SPACER
129	2041101-09010-0	O - RING
130*	11327-0370001-4	BUMPER
131	1136D-0374701-1	PRESS RING
133	11397-0794701-1	GUIDE COVER
201	2041104-02020-0	O - RING
202	2041104-02030-0	O - RING
203	11374-0084701-1	PLUNGER CAP
204	1133S-0250001-1	VALVE PLUNGER
205	2041100-01070-0	O - RING
206	2041100-01030-0	O - RING
208	11375-0084701-1	PLUNGER
209	2041102-01030-0	O - RING
210	11373-0084701-1	TRIGGER VALVE HEAD
211	2040400-05060-0	SPRING PIN
212	2040401-05100-0	SPIRAL PINS
213	11224-0374701-2	TRIGGER UNIT
214	2040401-05160-0	SPIRAL PINS
216	11318-0374701-1	TRIGGER PIVOT PIN
217	1131D-0460001-1	URETHANE RETAINER
301	11230-0795201-1	GUN BODY UNIT
302	2041106-07010-0	O - RING
303	11346-0374301-1	END CAP
304	1135V-0000001-1	AIR PLUG
305	1132L-0014701-2	DUSTY COVER

306	1136U-0794701-1	FILTER
401	2041104-07010-0	O - RING
402	2041100-01020-0	O - RING
403	11382-0794705-3	NOSE PIECE
404	2040101-05040-1	HEX.SOC.HD.BOLT
405	1135H-0790001-1	PU RETAINER
406	11306-0794701-4	FEED FINGER
407*	11307-0790001-1	FEED FINGER SPRING
408	11365-0794701-1	PIN FEED PISTON
409*	2041100-01090-0	O - RING
410	11364-0794701-1	FEED PISTON
411*	2041104-03020-0	O - RING
412	1133F-0794701-1	FEED PISTON SPRING
413	1134W-0790001-1	FEED BUMPER
414	11366-0794701-1	FEED PISTON CAP
415	2040300-04010-0	C - RING
416	1133C-0790001-2	STOPPER FINGER SPRING
417	11361-0794706-1	DOOR
418	11358-0794704-1	NAIL STOP
419	2040401-04060-0	SPIRAL PINS
420	1131G-0254701-1	FIXED RING
421	11310-0864701-1	DOOR LATCH
422	11311-0974701-1	LATCH SPRING
423	11324-0254701-1	FIXED PIN
424	11362-0794704-1	DOOR SHAFT PIN
425	11338-0374701-1	SAFETY GUIDE
426	11337-0794701-1	SAFETY SPRING
427	11330-0794703-1	SAFETY
432	1132V-0794702-1	PIN
433	11355-0794702-1	MAGAZINE COVER
434	1131G-0794702-1	FIXED RING
435	1134M-0864701-1	SPRING BASE
436	11328-0794701-1	PULL SPRING
437	11289-0790001-1	SPACER
438	11357-0794701-2	ADJUST POST
439	11354-0794702-3	MAGAZINE CASE
440	11398-0254702-1	LATCH SPRING BUSHING
441	2040201-04020-0	FLAT WASHER
442	2040101-04120-0	HEX.SOC.HD.BOLT
443	2040301-24010-0	C - RING
444	1134M-0250002-1	SPRING BASE
445	1134C-0794701-1	SAFETY COVER
446	2040501-04010-0	BOLT CAP
447*	11383-0790001-1	MUZZLE PROTECTOR
448	2040100-04030-0	BOLT ASSY
449	1135H-0860001-1	PU RETAINER
450	11337-1014701-1	SAFETY SPRING
454	2040200-06011-0	SPRING WASHER