

SPARE PARTS OF BASSO C38/100-A1 COIL NAILER

ITEM	PARTS NO	PARTS NAME
101	2040101-04121-2	HEX.SOC.HD.BOLT
102	11369-1035301-1	CAP
103	1135S-0350001-1	GROMMET
104	2040104-03010-0	HEX.SOC.HD.SCREW
105	11397-1034701-1	GUIDE COVER
106*	11302-1034701-1	CYLINDER CAP SEAL
107*	11370-1030001-1	SEAL
108	11360-1030001-2	COMPRESSION SPRING
109*	2041108-06050-0	O - RING
110	11381-1030001-1	WASHER
111	11368-1030001-1	HD.VALVE PISTON
112*	2041108-07050-0	O - RING
113*	2041100-06011-0	O - RING
114	11204-1030001-3	DRIVER UNIT
115	11399-1030001-1	COLLAR
116	11320-1030003-1	CYLINDER
117	11321-1030001-1	CYLINDER SPACER
118	2041104-11010-0	O - RING
119	2041108-07060-0	O - RING
120*	11327-1034702-1	BUMPER-A
121	2040101-03050-9	HEX.SOC.HD.BOLT
122	11371-1034701-1	DEFLECTOR
123	1132T-1030001-1	MUFFLER
124*	11327-1034703-1	BUMPER-B
201	2041104-02060-0	O - RING
202	11374-0860001-1	PLUNGER CAP
203	2041100-02050-0	O - RING
204	2041100-01070-0	O - RING
205	1133S-0860001-1	VALVE PLUNGER
206	2041100-01030-0	O - RING
207	11376-0860001-1	SPRING
208	2041108-01020-0	O - RING
209	11375-0860002-1	PLUNGER
210	11373-0860001-1	TRIGGER VALVE HEAD
211	11329-0860001-1	PIN
212	1137A-0860001-1	COVER-PLUNGER
213	2041104-02070-0	O - RING
214	2041100-01050-0	O - RING
215	2040401-05150-0	SPIRAL PINS
216	11317-0864701-2	SECONDARY TRIGGER
217	11316-0864701-3	TRIGGER
218	2040401-05080-0	SPIRAL PINS
219	2040401-05120-0	SPIRAL PINS
301	11230-1035201-2	GUN BODY UNIT
302	2041101-05020-0	O - RING
303	11346-0864303-1	END CAP
304	1132L-0014701-2	DUSTY COVER
305	1135V-0000021-3	AIR PLUG
401	2041104-08020-0	O - RING
402*	11383-1030001-1	MUZZLE PROTECTOR
403	11382-1034705-1	NOSE PIECE
404	2040101-06010-2	HEX.SOC.HD.BOLT

405*	2041100-01091-0	O - RING
406	11364-1034701-1	FEED PISTON-B
407*	2041104-03040-0	O - RING
408	1134W-0970001-1	FEED BUMPER
409	2040100-04080-2	BOLT ASSY
410	11367-1030001-1	PUSHER SPRING
411	11366-0974701-1	FEED PISTON CAP
412	2040300-08010-0	C - RING
413	1134B-0864701-1	DUST SHIELD PLUG
414	11310-0254702-2	LOCK LEVER
415	11311-1030002-1	LATCH SPRING
416	11361-1034701-4	DOOR
417	1135H-0860001-1	PU RETAINER
418	1131K-1034701-1	PIN
419	1133C-0860001-1	STOPPER FINGER SPRING
420	11358-0864701-1	NAIL STOP
421	11359-1034701-1	PIN-NAIL STOP
422	11362-1034701-1	DOOR SHAFT PIN
423	11330-1034701-1	SAFETY
424	11337-1030001-1	SAFETY SPRING
425	11338-0864701-2	SAFETY GUIDE
426	11354-1034702-1	MAGAZINE CASE
427	11357-1034702-1	MAGAEING POST
428	1138Y-0864701-1	RUBBER RING
429	1134M-0864701-1	SPRING BASE
430	11289-1030001-1	SPACER
431	1138W-0860001-1	SPACER
432	11328-0970001-1	PULL SPRING
433	11355-1034701-1	MAGAZINE COVER
434	11365-0864701-1	PIN FEED PISTON
435	11306-1034701-1	FEED FINGER
436	11364-0974701-1	FEED PISTON-A
437*	11307-0970001-1	FEED FINGER SPRING
438	2040101-04131-0	HEX.SOC.HD.BOLT
439	1134R-1034701-1	SPRING COVER
440	2040501-04010-0	BOLT CAP
441	1136R-1034701-1	MAGAZINE SHAFT PIN
442	2040202-04010-0	FLAT WASHER
444	1131D-0460001-1	URETHANE RETAINER
445	1135U-1010001-1	PROTECTOR WASHER
447	1120K-1034701-1	SECOND HANDLE BASE UNIT
448	1137K-1030001-2	HANDLE
449	1135S-1034701-1	GROMMET
450	1135G-1114701-1	RUBBER PAD