



NP45 PARTS LIST

| NO. CODE | Description | NO. CODE | Description |
|----------|---------------------|----------|-----------------------|
| 1 | GASKET | 29 | STRAIGHT PIN B3X15 |
| 2 | BACK BUMPER | 30 | TRIGGER VALVE CAGE |
| 3 | EXHAUST SEAL | 31 | O-RING 18.3X2.65 |
| 4 | COMPRESSION SPRING | 32 | O-RING 11.8X2.65 |
| 5 | HEAD VALVE PISTON | 33 | TRIGGER VALVE CAP |
| 6 | O-RING 40X2.65 | 34 | TRIGGER STEM |
| 7 | CYLINDER COLLAR | 35 | O-RING 2.5X1.4 |
| 8 | PISTON | 36 | TRIGGER VALVE SPRING |
| 9 | DRIVER BLADE | 37 | O-RING 8.6X1.9 |
| 10 | O-RING 30X3.55 | 38 | TRIGGER VALVE BUSHING |
| 11 | CYLINDER RING | 39 | O-RING 5.0X2 |
| 12 | O-RING 51.5X2.65 | 40 | O-RING 8.7X1.8 |
| 13 | CYLINDER | 41 | ROLL PIN 3X30 |
| 14 | O-RING 38.7X2.65 | 42 | DOWEL PIN |
| 15 | O-RING 38.7X3.55 | 43 | TRIGGER BRACKET |
| 16 | BUMPER | 44 | SPRING |
| 17 | BODY | 45 | ADJUSTER BUTTON |
| 18 | HANDLE GRIP | 46 | CONTACT PLATE |
| 19 | END CAP SEAL | 47 | SPRING |
| 20 | END CAP | 48 | TRIGGER |
| 21 | BOLT M5X22 | 49 | STEP PIN |
| 22 | 气缸O形圈 (一) 38.7X3.55 | 50 | PIN CAP |
| 23 | 缓冲垫 | 51 | O-RING 10X1.8 |
| 24 | 枪身 | 52 | NOSE |
| 25 | 手柄橡胶套 | 53 | BOLT M6X22 |
| 26 | 尾盖密封垫 | 54 | BRACKET |
| 27 | 尾盖 | P1 | DRIVER UNIT |
| 28 | 螺栓M5X22 | P2 | TRIGGER VALVE |